UniNeť

Quick Start Guide for the iColor 550



 Unpack the machine, check all components and remove the orange tape from all sides. Then open the top lid.









2. Remove the white toner cartridge. Remove protective foam from inside the machine and protective film from the white cartridge and reinstall.



3. Using the provided USB drive, install the driver. Refer to the User Manual for selecting the appropriate driver.

Only connect the Printer to the PC when prompted to by the software.

4. There are three possible configurations of the iColor 550. These coincide with the 'Print Queues' in the iColor ProRIP (Step 13).



5. Install the iColor ProRIP (stored on the provided drive)





Univet Imaging, Inc.
3232 West El Segundo Blvd
Hawthorne CA 90250
(621) 500-1040
(031) 330-1040

END USER LICENSE AGREEMENT

This End-User License Agreement (this 'BLA') is a legal agreement between you (Licensee) and Uniket Imangon, c. (Licensor'), the author of Uniket Cicol ProDip, including all HTM. Res, VM. Res, Java Res, graphics Res, animation Res, data Res, technology, devolgement tools, acroist and programs, both in object code and source co (the "Software"), the deliverables provided pursuant to this BLA, which may include associated media, printed materials, and "onine" or declaronic documentation.

By installing, copying, or otherwise using the Software, Licensee agrees to be bound by the terms and conditions set forth in this EULA. If Licensee does not agree to the terms and conditions set forth in this EULA, then Licensee may not download, install, or use the Software.

I accept the terms of the locrose agreement
I do not accept the terms of the locrose agreement
Constant accept the terms of terms of terms of terms of terms o









UniNet | sales@icolorprint.com | www.icolorprint.com

After the iColor ProRIP installation is complete, the setup will begin. Internet connection is required.

6. Confirm first time setup. And click 'OK'. First Time Setup	Create Queue Wizard	7. Click "Install Printer".	8. Choose the iCold	or 550 and click 'OK'.	
You are running iColor ProRIP for the first time. Please review initial settings and modify to suit your preferences.	Printer Defaults		Install Printer X Select a printer from the list you want iColor ProRIP to support		
Where applicable, all numeric values will be displayed using the selected units and number of decimal places set below.	Assign a default printer f	for this production queue. r, print mode, and output port for this queue:	Select none UniNet (Color 550	Clear Items selected: 1	
Set display units: inches ~ Set number of decimal places: 2	Printer:	Install Printer			
To change these settings, and for advanced options, click on 'Tools->Options' after the application begins.	Print mode:	· · · · · · · · · · · · · · · · · · ·			
		Back Next Cancel	Васк	OK Cancel	
9. To install the Print Queues click 'Next'.	Create Queue Wizard		10. Setup is I	now complete.	
Add Printer	Add Printer		Add Printer		

Add Printer	Add Printer		ldd Printer
Device Package Search	Copying Device Packages		Configuration Summary
 Search for new printer package(s) from DVD or Cloud server. Search Cloud server for printer package(s). Internet access required for this search to take place 	Overall copy progress Installation Complete		You have completed the Install Device Wizard. UniNet iColor 550 Driver package [Version 1.40]: Installed successfully
Search DVD. Please insert Printer DVD supplied with Rip Software O Don't search automatically, I will choose the search location Select this option if you would like to select a printer package from a specific location. This printer package may not be the most recent version available.	Download progress UNINT550.1.40.R.pkg64 From updater.cadlink.com Downloaded: 7.43 MB copied in 0 seconds Transfer rate: 16.03 MB/Sec		
Browse	Extraction progress Extraction Complete Device package update is complete. Click 'Next' to continue.		
Back Next Cancel	Back Next Cancel		Finish Back Next Cancel

11. Open the iColor ProRIP and click Queue/Manage Queues.

Y.	Manage Que	ies			2) 😌 💊 👰 🚎 🧔 🧭
Unit	Stop		iderp	int		🖕 🔊 💭 To width
Name	Clear Job Erro	rs		Conies		0.0 0.5 1.0 1.5 2.0 2.5 3.0 3.5 4.0 4.5 5.0 5.5 6.0 6.5 7.0 7.5 8.0
	Set maximum	white ink		Copies		8 -
	Setup black re	moval	a black			n -
	Set white cho	ke	er black			
	Setup color b	post				
	Setup photo r	nerge				23
	Properties		Alt+Q			9 ⁻
						ν ⁻
						8 -
						2 -
					>>	
						* -
						8 -
						2
						· -
					- 1	0.00
<					>	Gueue Page UniVet 2 Step Standard 550 Paper
Reserve	ed		Browse			M Sim 19 27 in 11 09 int
Name		Status	Print Mode	Copies		Av Side: (6.27 mX 11.05 m) V m
						hout Tray Tray1
						₩ 0.00 in () I 0.00 in () Output Resolution 600x600 ~
						++ 0.00 in 0 1 0.00 in 0 Paper Type Labels V FRONT
_						Color Adjust

13. Select your 'Print Que' and 'Print Mode'. The 'Print Modes' have preset values for white coverage, choke, paper size, paper tray and

12. In the 'Port' drop down menu, choose the port, and click 'Close'.



14. To load a file, click the green icon in the menu bar. Then choose the desired file. After, click the 'Print' icon in the menu bar.

mirror settings. These can be modified as needed.

Please note, the preview icon of the printer should match the physical configuration of the printer.



For detailed instructions please refer to the iColor 550 Printer User Manual and the iColor ProRIP User Manual UniNet | sales@icolorprint.com | www.icolorprint.com